

PNT 9710 The key to making electronic scales simple.

The First Truly Self-Diagnostic Indicator with On-Screen Programming Display Truck, Trailer and Total weights at the same time



Designed for flexibility, the PNT 9710 Weigh Indicator is the latest technology in on-board scale electronics for the trucking industry. It can be easily modified to meet the needs of changing system requirements.

The five user soft keys allow you to produce key functions that are unique to your application.

- Super-Bright, .6" high, red, seven segment LED display.
- Two-wire, non-polarity sensitive, digital technology provides ultimate reliability.
- An Advanced Calibration function for calibrating the scale without a load.
- Simple diagnostics allow each system component to be quickly checked from the cab.
- Capable of monitoring individual load cell outputs.
- Quick switching from GROSS to NET and quick TARE RESET.
- Load/Delivery mode for incremental load or delivery.
- Axle weight formula accurately calculates steering axle weight.
- Time and date to use with printer
- Multiple serial data ports are standard. Can be interfaced with printers, remote displays, bar code scanners, computers and other serial devices using RS-232 or RS-485.
- TTL logic port for relays or other control functions.
- Compatible with all models of On-board scale load cells and sensors.

For more information contact:



8294 28th Court NE Suite # 500
Lacey, WA 98516

Tel (360) 493-8344 - Fax (360) 491-6073
Call Toll Free **1-888-340-6246**
Or Visit <http://www.pntinc.com>